ASSEMBLY INSTRUCTIONS

ATTENTION: THIS PRODUCT IS NOT FOR COMMERCIAL USE
INTENDED FOR RESIDENTIAL USE ONLY.

KUS128X-WM

PARTS LIST

PART NO.	MATERIAL CODE	PART	Q'TY
1	KUS128X-CS01	REAR SEAT	1
2	KUS128X-CS02	LEG	2
3	KUS128X-CS03	FRONT SEAT	1
4	KFS128W-CS02	BACK ASSEMBLY	1
5	17C02A0712003Y4	BOLT M6*35	4
6	17C01A0714003Y4	BOLT M6*40	2
7	17XA3309	STEEL WASHER	4
8	17FA05040301-Y4	WASHER d6.5*D13*1.0	4
9	18000C23001	PLASTIC NUT M6*P1.0	2
10	18000337006	BOLT CAP M6	4
11	18000337002	BOLT CAP M6	2
12	17KAA0201----Y4	HEX.KEY WRENCH 6MM	1
13	17KAB1101----Y4	NUT WRENCH 10&13MM	1
14	61K128XX00001BA	BACK CUSHION	1
15	61K128XY00001BA	SEAT CUSHION	1

Attention:
Make sure that all bolts needed for each step matches the corresponding figure to ensure proper assembly.

Step 1:
Insert the rear seat (#1) into the legs (#2). Fasten the legs (#2) to the rear seat (#1) by using bolts (#5) and steel washers (#7). See Figure 1.

Note:
The labeled arrow marks on the legs (#2) should coincide with Figure 1 to ensure proper assembly.

FIGURE 1



⚠ Use the correct bolts as indicated. Do not tighten any of the bolts until is completely assembled.
⚠ Do not discard of any of the packaging until you have checked that you have all of the parts and fittings required.
⚠ Keep children away during assembly. This item contains small parts that can be swallowed by children. Children should always be under direct adult supervision while using this product.
⚠ Retain these assembly instructions for future reference.
⚠ Quote the following FQC NO. when contacting the service center.

SERVICE CENTER TOLL FREE NO.
TEL: 1-877-539-7436
FAX: 1-877-539-7439

STOP **DON'T RETURN TO STORE!**

FIGURE 2



Step 2:
Insert the rear seat (#1) into the front seat (#3). Make sure that the spring clips on the rear seat (#1) come through the holes on the front seat (#3). See Figure 2.

FIGURE 3



Step 3:
Fasten the back assembly (#4) to the rear seat (#1) by using bolts (#6), washers (#8), and plastic nuts (#9). Make sure that all of the bolts have been tightened completely and cover them with bolt caps (#10 and #11). See Figure 3.

FIGURE 4



Step 4:
Place the cushions (#14 and #15) onto the lounge. Secure the cushions to the lounge by using the plastic clamps. See Figure 4.

Cleaning and Maintenance

- Wash frame and fabric parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame or fabric parts.
- Cushions may be washed on the surface by only using mild soap and water or commercial foaming upholstery cleaner if necessary. If washed, rinse well and hang to dry. Do not machine wash or dry.
- We recommend the use of furniture covers when not in use.
- Inspect and tighten all bolts and fasteners on a regular basis to ensure the proper performance and safety of your lounge.
- In order to prolong the life and beauty of your lounge, we recommend that it be stored in a dry and protected area during the off season periods.

STOP!

Missing A Part?
No Need To Go Back To The Store

The store where you made your purchase does not stock parts for this item.
If you need parts,
whether they are missing or damaged,
Call Toll Free:
TEL: 1-877-539-7436
FAX: 1-877-539-7439
Call us between 9:00 AM and 4:30 PM
Eastern Time Monday through Friday

READ THESE INSTRUCTIONS COMPLETELY BEFORE STARTING ASSEMBLY

★SEPARATE AND IDENTIFY ALL PARTS, MAKING SURE THAT YOU HAVE ALL OF THE PARTS LISTED.
★IF YOU DO NOT LOCATE ALL OF THE PARTS LISTED, INSPECT THE PACKING MATERIAL FOR SMALL PARTS THAT MAY HAVE BECOME SEPARATED DURING SHIPMENT.
★IF YOU EXPERIENCE ANY DIFFICULTY DURING ASSEMBLY OR IF ANY PARTS ARE MISSING OR DAMAGED, CALL THE HELP LINE AT 1-877-539-7436 BEFORE RETURNING THIS ITEM TO THE STORE.
★PROVIDE THE FOLLOWING INFORMATION WHEN CALLING:
1-MODEL NUMBER OF THE PRODUCT.
2-PART NUMBER AND MATERIAL CODE OF THE PART FROM THE PARTS LIST.
★MOST PROBLEMS CAN BE RESOLVED WITHOUT RETURNING THIS TO THE RETAILER.PRODUCT

STOP **DON'T RETURN TO STORE!**